### Optical Design: Components and Techniques



- First Key Question:
  - What is the purpose of the accelerator / beamline?
    - » sets requirements on particle energy, luminosity/brilliance, beam size, acceleration rate, particle targeting rate, ...
    - » ...which sets requirements for B, B', ...
- Next Questions:
  - key parameters?
    - » aperture, final focus, momentum acceptance, momentum manipulations, high intensity, ...
  - special requirements?
    - » slow spill, e- stripping, diagnostic sections, collimators/halo removal, beam cooling, ...
  - also, number of users, or number of experiments:
    - » 10-100? (Light Source) 1-10? (HEP facility) 1-2? (medical), etc.



# **Optical Design [2]**



### • Further...

- choice(s) of technology?
  - » maximum field strengths, straight sections lengths, apertures, ...
  - » power consumption, real estate, ...
- system constraints?
  - » geometrical -- existing tunnel(s), beam line direction/orientation, accommodation of surface features, geological, ...
  - » components -- existing magnets, existing power supplies, diagnostics, accelerating cavities, ... COST! ...
- source(s) of particles?
- charge state(s), injection energy, emittances of existing beams, ...



# **Ex: Light Source**



- Synchrotron Radiation due to bending
  - want low dispersion function in the bending magnets
  - --> produces smaller equilibrium emittances

- Typically, lower energy (~1-10 GeV) electrons; many users!
  - thus, can tolerate lower "packing fraction":
    - » 2πρ/C < ~50%



# **Ex: HEP Synchrotron**



- Here, typically very high energy, few experiments (though still MANY users!)
  - need lots of bending, perhaps less need for free space in the system
  - may look like mostly FODO cells, with space for RF accelerating cavities, injection/extraction, etc.
  - here, typically much larger packing fraction (~80% or higher in the arcs)





# **Optical Modules**



- Very often useful to think of optical systems in terms of modules
- Each module has a purpose and/or special conditions to be met
  - general beam transport; achromatic; large dispersion for momentum selection, charge selection; small dispersion for isochronous transit; final focus onto target; long drift space for equipment; compact bending; etc. ...
- Large/long systems are best generated with (stable!) periodic lens systems -- may or may not have bending
- Often need longer spaces for instrumentation, RF, switching magnets, experiments, etc.
- May need to match one focusing structure into a different focusing structure (e.g., change of cryomodule lengths, etc.)
- Simultaneously trying to control  $(\alpha, \beta, D, D')_{x,y}$  [and sometimes  $\psi_{x,y}$ ] as well as X, Y, Z and X', Y' of the ideal trajectory along the beam line!
  - various computer programs are good at this



# **Doublets and Triplets**



- FODO Cells
  - basic transport; equal spacing; easy analysis
- Doublets
  - can be used to generate more space
- Triplets
- can be used to keep beam "round"









### **Quarter-Wave Transformer**



Suppose want to transform from one focusing pattern to another...



### **Quarter-Wave Transformer [2]**



- So, adjust k (i.e.,  $L_0$  and f) to get the desired  $\beta_2$
- Then, re-adjust q/2 at the end to get the desired  $\alpha_2$



Once have b2, may not have the *desired* α2 needed for the match into the new FODO cells; so, re-adjust α2 by adjusting the last quad of the transformer:

 $\Delta \alpha_2 = \beta_2 \cdot \Delta q$ 

Note: since start with  $\beta_x = \beta_y @$  pt. 1, then get  $\beta_x = \beta_y @$  pt. 2

AND 
$$\alpha_x = -\alpha_y @ \text{ pt. } 1 \longrightarrow \alpha_x = -\alpha_y @ \text{ pt. } 2$$

AND when re-adjust,  $\Delta \alpha_x = \beta_x \Delta q = -\beta_y \Delta q = -\Delta \alpha_y$ 

which automatically maintains  $\alpha_x = -\alpha_y$  condition at pt. 2



### **Collins Straight Section**



Northern Illinois University



# **Collins Straight Section [2]**



- Note: in order to match H and V optics *simultaneously*, we want  $a_x = -a_y$  and  $\beta_x = \beta_y$  at the match point(s).
  - this occurs in the middle of a FODO cell...



### **Final Focus**





To tune, consider starting at the target with a desired  $\beta = \beta^*$ , and  $\alpha = \alpha^* = 0$ , and working backward to find values for tuning quads that match  $\beta_x$ ,  $\beta_y$  back into the transport region



tune 4 quads to match 4 parameters  $(\beta, \alpha)_{xy}$ 

 $\hat{\beta} \approx \frac{L^2}{\beta^*}$ 

# Final Focus [2]



- FRIB Final Focus:
- Beam size max/min
  - max/min ~ 35
  - max(linac)/min(target) ~ 10





### **Double-Bend Achromat**





# **Dispersion Suppressor**





Then, using 3x3 matrix approach:

$$\begin{pmatrix} \vec{D}_0 \\ 1 \end{pmatrix} = \begin{pmatrix} a & b & e \\ c & d & f \\ 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} \vec{D}_0 \\ 1 \end{pmatrix} = \begin{pmatrix} M_0 & (I - M_0)\vec{D}_0 \\ 0 & 1 \end{pmatrix} \begin{pmatrix} \vec{D}_0 \\ 1 \end{pmatrix}$$



# **Dispersion Suppressor**



So, we transport through a cell with bending reduced by factor (1-x) followed by a cell with bending reduced by factor *x*; since  $D \sim \theta$ , then the matrix elements scale accordingly and hence...



$$\begin{array}{ll} \text{final} \\ \text{dispersion} \\ \neq 0 \end{array} \quad \begin{pmatrix} \vec{0} \\ 1 \end{pmatrix} = \begin{pmatrix} M_0 & x(I - M_0)\vec{D}_0 \\ 0 & 1 \end{pmatrix} \begin{pmatrix} M_0 & (1 - x)(I - M_0)\vec{D}_0 \\ 0 & 1 \end{pmatrix} \begin{pmatrix} \vec{D}_0 \\ 1 \end{pmatrix} \quad \begin{array}{l} \text{initial periodic} \\ \text{values} \end{pmatrix}$$

which, upon simplification, yields  $\vec{0} = \left[(1-2x)I + x(M_0^{-1} + M_0)\right]M_0\vec{D}_0$ 

Noting that  $M_0^{-1} + M_0 = trace(M_0)I = (2\cos\mu)I$ 

 $\mathcal{X}$ 

then our equation is satisfied if

$$=\frac{1}{2(1-\cos\mu)}$$





### **Dispersion Suppressor Example**



Northern Illinois University

H

NIU

M. Syphers **PHYS 790-D** FALL 2019 16

## **FODO Achromatic Bend Sections**





# **LHC Straight Sections**





Standard Cell

#### **Acceleration Region**



#### **Extraction Region**



#### **Emittance Cleaning**



#### Momentum Cleaning



#### **Interaction Region**





# The Superconducting Super Collider



Northern Illinois University



(~1990...)





## Superperiodicity



### Racetrack vs. multiple superperiods





However, the clustered scheme is more cost effective because of considerations concerning the conventional facilities and so was recommended for the SSC concentual design

Generally speaking, evenly distributed IRs permit a higher superperiodicity and thus fewer resonances in the tune space. For the case of SSC, this means a superperiodicity of 6, if the utility sections and crossings are ignored. Realization of the consequences of high superperiodicity requires correlation of particle motion in magnets that are separated by 1/6 of the ring circumference, i.e., about 14 km. Because of various magnet field and alignment errors, correlation over this long distance is not likely to be maintained. The superperiodicity is thus broken in reality and all low-order resonances, systematic and accidental, need to be avoided.

The fact that a high superperiodicity is not very important for the SSC is demonstrated by particle tracking using the programs PATRICIA [4.2-8] and RACETRACK [4.2-9] on

eral was found to dotoriorate as compared with the two family schem

There is a potential optical advantage of IR clustering. Compared with distributed IRs, clustered IR lattices have one more variable to control the optical quality, namely, the betatron phase advance  $\mu$  between adjacent IPs in a cluster. The optimum value of  $\mu$  is found to be an odd multiple of  $\pi/2$  [4.2-7, -11, -12]. By pairing IRs in a cluster and setting  $\mu$  to the optimum value, one minimizes the chromatic aberrations of particle motion. This optimum phase also helps to reduce the orbit effect from long-range beam-beam interactions and to suppress some of the incoherent beam-beam resonances.

To be more specific, the tune dependence on momentum is described to first order by

#### FNAL: original Main Ring had P = 6; Tevatron: P = 1!

# Magnet Arrangement: 2-in-1 / 1-in-1 / H / V



Northern Illinois University

### Vertical 1-in-1 chosen for the SSC, following extensive studies and workshops



The beams are separated vertically by 70 cm in the arcs. The magnets in the arcs are arranged in an over-under configuration rather than side by side. The 70 cm separation allows the magnets of the two rings to be decoupled cryogenically as well as magnetically. The over-under arrangement has the advantages that the tunnel space can be utilized more effectively and that the path lengths between collision points in the two rings can be more easily equalized. The decoupled magnets allow separate operation of the two rings. This makes it possible to perform accelerator physics studies on, one ring when the other ring is not available [4.2-3].

In a side-by-side arrangement, the horizontal dispersion introduced by the separation section can be removed by the horizontal dispersion suppressor already incorporated in the lattice. In an over-under arrangement, the vertical dispersion caused by the vertical separation section has to be compensated by an additional vertical dispersion suppressor. This can be done in two ways, depending on whether the beam separation starts immediately after the IR triplets (the early separation scheme) [4.2-2] or about 200 m after the triplet (the late separation scheme) [4.2-4]. The former allows more flexibility for operating and making corrections on the two rings separately and it minimizes the long range beam-beam perturbations. Early separation also makes it easier to remove the forward secondary particles that are generated by beam collisions. The latter has the advantage that the beta functions are more easily controlled, giving smaller beta function values in the matching quadrupoles beyond the main triplets.

The present conceptual design adopts the early separation scheme. The vertical dispersion suppression is accomplished by dividing the 70 cm separation into two steps and then introducing a FODO section which has 180 degree phase advance between the two steps. The vertical dispersion contributions from the two steps cancel outside the separation region.

### **Collider Parameters**



Northern Illinois University

From the SCDR		Collider Lattice Parameters (Footprint Version)			
Table 4.1.1-1		Energy: injection, collision (TeV) Magnetic radius (m) Magnetic field (T) Rigidity (T-m) Gradient (T/m) Circumference (484 cell lengths) (km) Arc length, cluster length (km) Half-cell length, arc sector length (m) Long straight section length, bypass length (m)	2 10187.1896 6.55 66712.8 205.6 87.12 35.28 90 1350	20 8.28 4320 4770	
Energy Particles/bunch (N) Circumference No. of bunches (B) NB frot fcollisions S <sub>b</sub> $\varepsilon_N(\sigma)$ $\beta^*$ $\sigma^*(\mu m)$ Luminosity ( $\mathcal{L}$ ) $\mathcal{L}/hit$ $\Delta v_{HO}$ (total) $\Delta v_{LR}$ (total) Sync. rad. power at $NB = 1.3 \times 10^{14}$	20 TeV $0.75 \times 10^{10}$ 87,120 m 17,424 $1.3 \times 10^{14}$ 3.4 kHz 60 MHz 5.0 m $1 \pi$ mm-mrad 1/2 m 5 $1 \times 10^{33}$ cm <sup>-2</sup> s <sup>-1</sup> $1.6 \times 10^{25}$ cm <sup>-2</sup> 0.003 0.004	Drift lengths at IP: Iow-B, medium-B IRs (m) Drift lengths in utility straight: center, ends (m) IP-IP distance: inner, outer (m) IP-IP bending angle (mrad) Minimum IP to muon beam clearance (m) Vertical beamline separation (m) Cell phase advance (deg)	±20 500 2160 40 34 0.80 90	$\pm 120$ 161 2520	
					Betatron tune: outer, inner bypass branch Phase advance between IPs: outer, inner branch Chromaticity: collision, injection optics Transition energy- $\gamma_{T}$ Momentum compaction ( $\alpha$ )
		Crossing angle (µrad) Bunch spacing (m) rf wavelength (m) Lengths of cell dipole, quadrupole (effective)* (m Bend radius, average arc radius (km) Bend angle per arc, per cluster (deg) Maximum number of IRs: simultaneous, total Cells per arc, cluster length in equivalent cells	<150 5 0.8333 0) 12.7 10.187 168 5 196	5.2 12.032 12 9 46	
					8.75 kW/ring
			$\eta_{\text{max}}, \eta_{\text{min}} \text{ in arc (m)}$ $\beta^* \text{ in low-}\beta \text{ IR: injection, collision (m)}$ $\beta^* \text{ in medium-}\beta \text{ IR: injection, collision (m)}$	1.82 8 60	0.8 0.5 10

축

 $\beta_{\text{max}}$  in low- $\beta$ , medium- $\beta$  IRs (collision) (m)

 $\beta_{\text{center}}, \beta_{\text{max}}$  in utility straight (m)

\*See Tables 4.1.1.1-3 and 4.1.1.1-7.

7990

300

2657

970









M. Syphers

# **Utility Region**





Figure 4.1.1.1-9. Utility straight section: (a) lattice and orbit functions and (b) functional elevation-view schematic.



### **Injection/Collision Regions**





Figure 4.1.1.1-12. Lattice and orbit functions of low- $\beta$  IR in injection optics.

Figure 4.1.1.1-11. Lattice and orbit functions of low- $\beta$  IR in collision optics.

![](_page_24_Picture_5.jpeg)

### **The Diamond Bypass**

![](_page_25_Picture_1.jpeg)

![](_page_25_Figure_2.jpeg)

Figure 4.1.1.1-2. Layout of west campus region.

TIP-00644

![](_page_25_Figure_4.jpeg)

### **Lattice Decisions**

![](_page_26_Picture_1.jpeg)

- I-in-1 assured can operate one ring without the other
  - except: the IR triplets were "shared" by both
  - desire was to be able to commission one ring if the other was not ready
  - Vertical "-I" beam lines made IR tuning transparent
- IR designs were still being finalized at project end

![](_page_26_Figure_7.jpeg)

![](_page_26_Picture_8.jpeg)

Fig. 1. Vertical view of an IR.

# **Dispersion Suppressor**

![](_page_27_Picture_1.jpeg)

![](_page_27_Figure_2.jpeg)

Figure 4.1.1.1-8. Lattice functions of the normal cell C, the dispersion suppressor D, and empty cell CO.

28

FALL 2019

### The "10F" Lattice

![](_page_28_Picture_1.jpeg)

Northern Illinois University

i.e., Version 10, sub-version F (1993)

"holes", and the role of modularity in the final layout

![](_page_28_Picture_5.jpeg)

- "free space" created in arcs
  "missing" dipolog in college
  - "missing" dipoles in cells

![](_page_28_Figure_8.jpeg)

Figure 7-1. Schematic Layout of the Free Space in the Collider.

## Modularity and "free space"

![](_page_29_Picture_1.jpeg)

 Modularity and "free space" became very useful when finalizing the exact locations of shafts, utilities and service buildings

![](_page_29_Figure_3.jpeg)

![](_page_29_Picture_4.jpeg)